



① PREPARE ② TREAT ③ MAINTAIN

# HOW TO TAKE CARE OF YOUR LACQUERED FLOORS



WOCA Denmark A/S · Tværvej 6 · 6640 Lunderskov, Denmark  
Tel. +45 9958 5600 · info@wocadenmark.com · wocadenmark.com

406122UK 082020



FLOORS

## REGULAR CLEANING

simple and fast



### MASTER CLEANER

- Effective care and cleaning
- Produces a stronger, more resistant surface
- Fast and easy to use



#### WORKFLOW

- 1 For daily cleaning, mix 125 ml Master Cleaner with 5 L of hot water.
- 2 Wash the floor along the length of the floor covering.
- 3 It is important that no water is left on the floor after cleaning.



## REJUVENATE

when needed



### STEP 1 - INTENSIVE WOOD CLEANER

- Prepares surfaces for additional treatment
- Basic cleaning and grease removal
- High efficiency



#### WORKFLOW

- 1 Mix 250 ml of Intensive Wood Cleaner with 5 L warm water.
- 2 Wipe the wood surface with a well-wrung mop. For best results, leave Wood Cleaner solution on the surface to work for 5 minutes and wipe again with clean water. If necessary, the surface can be cleaned with a hand-held pad or a floor machine. If the surface is very dirty, repeat.
- 3 Let the surface dry completely before subsequent treatment.



### STEP 2 - MASTER CARE

- Care treatment to refresh floors
- Extends the lifetime of the floor
- Protects against wear and scratches



#### WORKFLOW

- 1 Shake the container well before use.
- 2 Apply the concentrated care product in a thin and even coat, using a WOCA Wool Pad and WOCA Pad Holder. If the cloth/mop becomes dirty, rinse in clean water and wring thoroughly. Then continue the application. Do not apply additional Master Care once a surface has begun to dry.
- 3 Leave the floor to dry for approx. 60 min. before use. No polishing or other treatment is required afterwards.