



1 PREPARE 2 TREAT 3 MAINTAIN

MASTER FILLER AQUA

PRODUCT DESCRIPTION

Master Filler Aqua is a water-based, thick and easy-to-sand gap filler for joints, holes and cracks in wooden parquet floors in e.g. brick or herringbone patterns. The filler produces a uniform finish, is extremely easy to work with and will not crack as it is elastic and allows the wood to work.

APPLICATION AREA

For filling new, untreated, newly-sanded and previously treated wooden surfaces. Ideal for all species of wood.



Drying time

Before sanding: 60 minutes at 20 °C.
For larger joints, the filler should be left to dry until the following day.



Easy to sand

Thick, elastic consistency. Easy to sand once it has cured.



Water-based

High-quality water-based acrylic gap filler.
Odour neutral.

Product information

Coverage: 15-20 m²/L
Packaging: 5 L





WORK DESCRIPTION

Preparation

The surface must be completely clean, dry and free of dust, wax, grease, polish, etc. Grime and irregularities should be removed using a sanding machine. Before application of Master Filler Aqua, use grit 60-80 sandpaper for a final sanding.

Mixing ratio

Mix 10-15 % sanding residue with Master Filler Aqua.

Note

Be aware of compatibility issues for woods with high tannic acid levels, or for exotic wood species.



APPLY



SAND



APPLY LACQUER

TREATMENT

- 1 Shake the container well before use.
- 2 Mix the Master Filler Aqua and the sanding residue into a nice and soft paste. The structure of the filler can be adjusted using the fine or coarse sanding residue.
- 3 Distribute the filler evenly, using a stainless steel applicator. Repeat if necessary.
- 4 Sand the surface with grit 100-120 sandpaper once the surface is dry.
- 5 The surface can then be lacquered using one of WOCA's lacquers, following the product instructions.